

Drain Hole Drilling Instructions

Note: This drainage hole is recommended only for specific Borla products. Please contact Borla Performance Industries with your Borla part number prior to drilling your muffler.

1. Mark a centerline on the muffler end cap facing the front of the vehicle. Mark the drain hole on the centerline 1/8" from the inside edge of the endcap.
2. Use a metal-cutting drill-bit and carefully drill through the end cap.
3. Clean hole of any metal shavings.
4. Periodically check drainage hole for blockage.



Borla Performance Industries recommends that an exhaust shop or professional after market parts installer perform the installation of this system. However, if you decide to perform the installation on your own it is recommended that two people are used. This installation should not be performed by one person due to the risk of injury. Ensure the installers use all under car safety precautions including eye protection.

Please take time to read and understand the following...

By installing your Borla Performance Exhaust System, you indicate that you have read this document and you agree with the terms stated below.

It is the responsibility of the purchaser to follow all installation instruction guidelines and safety procedures supplied with your Borla Performance Exhaust System

Borla Performance Industries assumes no responsibility for damages occurring from misuse, abuse, improper installation, improper operation, lack of responsible care, or all previously stated reasons resulting from incompatibility with other manufacturer's products and/or systems.