

# ARCANE<sup>2</sup>

## ELECTRICAL ROUTING



**GROUND THE HARNESS  
TO THE SEAT ANCHOR BOLT  
MAKE SURE ITS A GOOD GROUND!**

**CONNECT THE TWO  
PUMP POWER EYELETS  
TWO PUMP GROUND EYELETS  
AND FUEL LEVEL WIRES TO THE HAT**

**PLUG AND PLAY TO FACTORY  
PUMP CONNECTOR FOR  
FUEL LEVEL AND OEM  
LIKE FUEL PRIMING**

**PASS THE FIREWALL RIGHT IN FRONT OF THE  
BODY CONTROL MODULE IN THE PASSENGER  
KICK PANEL. THE FUSES WILL STAY JUST INSIDE**

**ROUTE POWER WIRES TO  
BATTERY JUNCTION BOX  
AND PLACE EYELET UNDER EXISTING NUT**

**JN2NING**