

## Mustang 550/GT350 Rear Tow Hook Receiver Installation

- 1. Remove rear fascia or rear extractor.
- 2. Find center of rear crash bar and center the receiver. Then, match drill 2 5/16 holes in bottom of crash bar and up through the bottom section, as shown in drawing.
- 3. Install receiver with coupling nut, facing to the rear of car and tighten the 2 lock nuts with the 2 washers.
- 4. Remove license plate and measure up from bottom of fascia to bottom edge of receiver and make note of it.
- 5. Measure up on the outside of the fascia the same distance as noted and add 6 inches and make a mark on fascia.
- 6. Use a 1/8 drill and drill though the fascia center and the distance up from bottom of fascia.
- 7. Use a wire or small driver to make sure you are centered to the coupling nut of the receiver, if so drill a ¾ hole through the fascia. When tow hook is not used the license plate will cover hole.
- 8. Re-install the lower extractor.

Any questions email info@zl1addons.com or call PH 858 527 8727





