

## Specifications

### Alignment Specifications

**NOTE:** Measurements listed at curb load. Curb load is defined as "full service fluids, full fuel tank(s), no passengers and no cargo".

Item	LH	RH	Total/Split
<b>Front</b>			
Camber — (Base Coupe, Base Convertible, Performance Package Convertible, Track Package Convertible)	-0.72° ± 0.75°	-0.72° ± 0.75°	0.0° ± 0.75°
Camber — (Performance Package Coupe, Track Package Coupe)	-1.03° ± 0.75°	-1.03° ± 0.75°	0.0° ± 0.75°
Camber — (GT350)	-1.05° ± 0.75°	-1.05° ± 0.75°	0.0° ± 0.75°
Camber — (GT350R)	-1.12° ± 0.75°	-1.12° ± 0.75°	0.0° ± 0.75°
Caster — (Base Coupe, Base Convertible, Performance Package Convertible, Track Package Convertible)	7.12° ± 0.75°	7.12° ± 0.75°	0.0° ± 0.75°
Caster — (Performance Package Coupe, Track Package Coupe)	6.91° ± 0.75°	6.91° ± 0.75°	0.0° ± 0.75°
Caster — (GT350)	6.81° ± 0.75°	6.81° ± 0.75°	0.0° ± 0.75°
Caster — (GT350R)	6.92° ± 0.75°	6.92° ± 0.75°	0.0° ± 0.75°
Toe — (All Models Except, GT350, GT350R)	—	—	0.0° ± 0.20°
Toe — (GT350)	—	—	-0.10° ± 0.20°
Toe — (GT350R)	—	—	0.06° ± 0.20°
<b>Rear</b>			
Camber — (All Models Except, GT350, GT350R)	-1.50° ± 0.75°	-1.50° ± 0.75°	—
Camber — (GT350)	-0.75° ± 0.75°	-0.75° ± 0.75°	—
Camber — (GT350R)	-0.70° ± 0.75°	-0.70° ± 0.75°	—
Toe — (All Models Except, GT350, GT350R)	0.12° ± 0.20°	0.12° ± 0.20°	0.23° ± 0.20°
Toe — (GT350, GT350R)	0.15° ± 0.20°	0.15° ± 0.20°	0.30° ± 0.20°