



Network Message Chart - Climate Controlled Seats

SCME Network Input Messages

Broadcast Message	Originating Module	Message Purpose
Climate control seat settings request	<u>FDIM</u>	The climate control seat settings request message contains the climate controlled seat request information.
Climate control seat settings request	<u>FCIM</u>	The climate control seat settings request message contains the climate controlled seat request information.

FDIM Network Input Messages

Broadcast Message	Originating Module	Message Purpose
Climate control seat settings status	<u>SCME</u>	The <u>SCME</u> provides this message to the <u>FDIM</u> for the purpose of updating the displayed status of the climate controlled seat buttons on the <u>FDIM</u> (touchscreen).

FCIM Network Input Messages

Broadcast Message	Originating Module	Message Purpose
Climate control seat settings status	<u>SCME</u>	The <u>SCME</u> provides this message to the <u>FCIM</u> for the purpose of updating the displayed status of the climate controlled seat buttons on the <u>FCIM</u> .