

# Glove Compartment



## Removal

### Glove compartment

1. The glove compartment and the passenger knee air bag are serviced as an assembly.  
Refer to: [Passenger Knee Airbag](#) (501-20B Supplemental Restraint System, Removal and Installation).

### Glove compartment upper stowage bin latch

2. Remove the instrument panel.  
Refer to: [Instrument Panel](#) (501-12 Instrument Panel and Console, Removal and Installation).
3. Remove the bolts, slide the glove compartment upper stowage bin off the bracket and remove the glove compartment upper stowage bin.