

**NOTE: x's are not to be changed (ignore), just change the positions indicated by letters/numbers/?**

**As Built Link >**

<https://www.motorcraftservice.com/AsBuilt>

Description	Module	Line
12v Powerpoint Timeout (Default)	BCM	726-39-01 : 1194 xxxx xxxx
12v Powerpoint Timeout (Immediate Timeout) this changes the 12v power outlets on the dash and in the center console	BCM	726-39-01 : 0001 xxxx xxxx
Auto-Relock - If you unlock your car by remote/fob, but don't open a door, then vehicle re-locks after 45 seconds	BCM	726-15-02 : 0101 0101 01xx
Auto-Relock Option in Instrument Cluster (Note: must set Auto-Relock to enable in BCM also to get auto-relock option to work)	IPC	720-01-01 xxxx ?xxx xxxx
Average Speed Indicator on Instrument Cluster - Note: will show average speed you've driven between trip resets	IPC	720-01-01 xxxx x?xx xxxx
Base->Sync3 Swap, Enable Drive Mode Toggle EB&V6	ABS	760-02-02 : xxxx 1xxx
Base->Sync3 Swap, Enable Drive Mode Toggle GT noPP	ABS	760-02-02 : xxxx 3xxx
Base->Sync3 Swap, Enable Drive Mode Toggle GT PP	ABS	760-02-02 : xxxx 7xxx
Base->Sync3 Swap, Enable Drive Mode Toggle Part 2	IPC	720-06-01 : xxxx xxxx x8xx
Base->Sync3 Swap, Fix Hazard Toggle	BCM	726-29-02 : xxxx xxx0 xx
Blindspot Option on IPC - Enable/Disable (if you have the driver/passenger Blindspot mirrors)	IPC	720-03-01 ?xxx xxxx xxxx
Cross-Traffic Alert (Note: This only changes what is displayed on the Instrument Cluster, you still need hardware changes for functionality)	IPC	720-01-01 xxxx xxxx ?xxx
Dark Car/Police (Stealth) Mode - keeps your interior (and Pony) lights off when you enter/exit/turn off vehicle	BCM	726-32-01 : xxxx x?xx xxxx
Door Ajar Chimes	IPC	720-01-02 : xx?x xxxx xxxx
Door Lock Horn Honk - Disable/Enable (this is the horn honk you get when you press Lock twice on your keyfob)	BCM	726-38-02 xxx? xxxx xxxx
Door Lock In Motion - Automatically locks your doors when vehicle reaches 12mph (std in US, but some export-spec are disabled)	BCM	726-15-01 x?x? x?x? x?xx
Double Honk Reminder - Enable/Disable (Engine On, No Keyfob) this is the double horn honk you get when the car is running, you get out (with the keyfob) and close the door	BCM	726-41-02 : xxx? xxxx xxxx
Engine Noise (Fake) / Active Noise Cancellation (ANC) - Disable ( <b>Ecoboost &amp; GT350 only</b> ) Note: May affect some aftermarket Subwoofers	ACM	727-01-01 : xxxx x?xx xxxx
Engineer Test Mode		<a href="https://youtu.be/StYM-b8cos8">https://youtu.be/StYM-b8cos8</a>
Gauges - Vacuum/Boost on Instrument Cluster	IPC	720-06-01 xx7x xxxx xxxx

**NOTE: x's are not to be changed (ignore), just change the positions indicated by letters/numbers/?**

**As Built Link >**

<https://www.motorcraftservice.com/AsBuilt>

Description	Module	Line
Gauges - Vacuum/Boost, Oil Pressure, and Transmission Temp (works on Autos only) on Instrument Cluster (NOTE: change just 7F to get only vac/boost and oil pressure...no trans temp for those Manual types)	IPC	720-06-01 xx7F 8xxx xxxx
Lights - DRL (Daytime Running Lights), allows you to control the Fog Lights (if you have 'em) to be activated as your DRLs through the Instrument Cluster (IPC), you must set all 4 lines to the right for this to work properly	BCM BCM BCM IPC	726-16-02 x1x1 x1x1 x1xx 726-21-01 xxxx xxxx x1xx 726-50-01 04xx 720-02-01 xx?x xxxx xxxx
Lights - DRL Options, Allow All DRL Choices	BCM	726-45-01: xxxx 7Fxx xxxx
Lights - DRL Options, DRL Choices Option 1-Change BCM 726-26-02: x1xx xxxx xxxx (Enables Parking Lights as DRL) Option 2 - Change BCM 726-26-02: xxx0 xxxx xxxx (Disables DRL switching while using Turn Signals)	BCM	726-50-01: ??xx
Lights - Fog Lights & Parking Lights DRL to come on automatically without using Light switch(es)	BCM	726-26-02: x1xx xxxx xxxx 726-45-01: xxxx 7Fxx xxxx 726-50-01: 04xx
Lights - Fog Lights Off with Turn Signal	BCM	726-28-02 : xxxx x1xx xxxx
Lights - Fog Lights Stay On when using Turn Signal	BCM	726-28-02 : xxxx 0000 xxxx
Lights - Sequential Turn Signal Enable/Disable (all 3 bars light up at same time if disabled)	BCMB	7B7-03-01 x?xx xxxx
Lights - Simultaneous High Beams & Fog Lights (Enable/Disable)	BCM	726-27-01 : xxxx xxx? xxxx
Line-Lock Enable/Disable (GT Only)	ABS & IPC	Must enable/disable on both modules
Lock Menu in IPC - Provides you with options in Vehicle ----> Settings ----> Locks (will provide you options to select/deselect Auto-Relock, Remote Lock, Mislock (?), etc.	IPC BCM	720-01-01 xxxx 5xxx xxxx 726-15-02 0101 0101 01xx
MFT - Navigation Enable (Note: You still need a Nav license file and the Nav SD card installed in your car-See separate Tab at bottom for steps)	APIM	7D0-01-02 x?xx xxxx xxxx
MyColor Power - Door Sills : Convertibles Only (allows you to control the color of illuminated door sills)	BCMB	7B7-01-01 : xxx2 xxxx x3xx
MyColor Power & Support	BCMB	7B7-01-01 : xxx0 xxxx x0xx
MyColor Power & Support (hardware required)	BCMB	7B7-01-01 : xxx2 xxxx x2xx

**NOTE: x's are not to be changed (ignore), just change the positions indicated by letters/numbers/?**

**As Built Link >**

<https://www.motorcraftservice.com/AsBuilt>

Description	Module	Line
Navigation In Motion - Enable/Disable (Note: This will also disable Sirius Travel Link/911 Assist, Vehicle Health Report, and Changes vehicle clock time by several hours)	APIM	7D0-02-01 : x?xx xxxx xxxx
Panic Alarm On Fob Disabled	BCM	726-37-01 xxxx xxx0 xxxx
Panic Alarm On Fob Enabled	BCM	726-37-01 xxxx xxx2 xxxx
Panic Alarm On Fob Requires 2 Presses	BCM	726-37-01 xxxx xxx1 xxxx
Rear Axle Ratio (3.15)	BCM	726-12-01 : 013B xxxx xxxx
Rear Axle Ratio (3.31)	BCM	726-12-01 : 014B xxxx xxxx
Rear Axle Ratio (3.55)	BCM	726-12-01 : 0163 xxxx xxxx
Rear Axle Ratio (3.73)	BCM	726-12-01 : 0175 xxxx xxxx
Rear Axle Ratio (4.10)	BCM	726-12-01 : 019A xxxx xxxx
Rear Parking Aid - Car Icon on Screen (most have this already, but great for those doing Sync swaps)	PAM	736-01-01 xxxx xxx? xx
Rear Parking Aid Option on IPC - Enable/Disable	IPC	720-02-02 ??xx xxxx
Remote Window Open - Press and release unlock on fob, then press and hold unlock button (NOTE: Remote Window Close will not work due to hardware limitation)	BCM	726-17-02 : x?x? x?x? x?xx
Seatbelt Reminder Chimes - Enable/Disable (turns off the chime/sound, but does not change when the instrument cluster light will illuminate)	IPC	720-01-01 : xxxx xx?x xxxx
Secure Idle - Enable (Automatics Only)	BCM	726-42-01 : x1xxx xxxx xxxx
Speedometer Correction - Change tires/rearend	BCM	726-12-01 : xxxx ???? xxxx
Steering Wheel Control Buttons - Switches the 5-way control button functions from the left side to the right side, and vice-versa (Note: This only moves the up/down/left/right/ok functions from one side to the other, it DOES NOT affect the cruise/voice command/etc buttons below the 5-way buttons)	SCCM	724-01-01 xxxx ?xxx xx
Stereo - Flat Line Out (enables flat/low output so you can hook up amps or disconnect subs)	ACM	727-01-01 xx5A xxxx xxxx 727-01-02 00xx
Stereo - Volume Indicator on Sync Screen (round or square)	APIM	7D0-01-01 xxxx ?xxx xxxx
Stereo Extended Play	APIM	7D0-01-01 : xx?x xxxx xxxx
Sync 2 - Radio Station Label instead of frequency (if station has RDS) Note: Useful if you have swapped equipment	APIM	7D0-01-01 xxxx xxxx ?xxx
Sync 3 - Adds HD Radio Available on radio settings screen (if radio HD capable) Note: Useful if you have swapped equipment	APIM	7D0-01-01 xxxx-xxx3-xxxx

**NOTE: x's are not to be changed (ignore), just change the positions indicated by letters/numbers/?**

**As Built Link >**

<https://www.motorcraftservice.com/AsBuilt>

Description	Module	Line
Sync 3 - Change colors of buttons on bottom of screen (volume overlay and music track progress bar colors also change) NOTE: You will now get 'Ford' shutdown screen	APIM	7D0-03-01 xxxx x?x? xxxx
Sync 3 - Display Soft Climate Buttons (Seat Cooling & Heating & Heated Steering Wheel) on Home Page	APIM	7D0-01-01 : xxxx xxxx x?xx
Sync 3 - HD Radio Enable (if radio HD capable) Note: Useful if you have swapped equipment	ACM	727-01-01 x0xx-xxxx-xxxx
Sync 3 - Radio Station Label instead of frequency (if station has RDS) Note: Useful if you have swapped equipment	APIM	7D0-01-01 xxxx xxxx ?xxx
Sync 3 - Remove Sirius from Audio sources (useful if you no longer have the Sirius subscription and want to remove as an audio source)	APIM	7D0-01-01 ?xxx xxxx xxxx
Sync 3 Lincoln/brown background theme - (Note: you will get the brown Lincoln theme screen, but you will also get the Lincoln shutdown screen...startup screen is unaffected)	APIM	7D0-01-02 8xxx xxxx xxxx 7D0-03-01 xxxx x2xx xxxx
Sync 3 Shutdown Screen - Note: this may also affect the Sync 3 theme as well	APIM	7D0-03-01 xxxx x?xx xxxx
Sync 3 Startup Animation - Will show vehicle screen at startup and will set Sync 3 display to vehicle standard	APIM	7D0-02-01 : xxxx x?xx xxxx
Temperature Display - Disable (turn off temp. display on Sync screen)	APIM	7D0-02-02 x?xx xxxx xxxx
Tire Mobility Kit Option on IPC - Disable/Enable	IPC	720-03-02 ?xxx xxxx
TPMS (Tire Pressure Monitor System) - Disable/Enable	BCM	726-08-01 : x?xx xxxx xxxx
Turn Signal - Hyper-Flash Disable (turns off the quick flash of turn signal if you have a turn signal bulb out/broken - great for folks upgrading to LED bulbs)	BCM	726-27-01 x?xx xxxx xxxx
Turn Signal - Lane Change # of Flashes (quick/temporary movement of turn signal lever)	SCCM	724-01-01 : xxxx x?xx xx
Vehicle Chimes Location (where vehicle chimes are heard from)	IPC	720-01-01 xxxx xxx? xxxx
VIN #	BCM	726-09-01



















































**Current as of: 13 Aug 2018**

Action	Contributor/ Verified By:	
Enable (Default-74 minutes 44 seconds)		
<u>Calculate different timeout periods</u>	DeltaNu1142	
Enable	solodogg	
Change ? To: 1-Disabled (off-default), 5-Enabled (on)	solodogg	
Change ? To: 0-disable (off), 4-enable (on)		
Enable		
Enable		
Enable		
Enable - must enable one of the above Drive Modes first		
Enable		
Change ? To: 2-Disabled (off), 6-Enabled (on)	solodogg	
Change ? To: 6-disable, 7-enable		
Change ? To: 0-Disable (off-default), 1-Enable (on)	AngelDeath	
Change ? To: 0-Disable (off), 1-Enable (on-default)	gt_stang	
Change ? To: 0-Disable (off), 1-Enable (on-default)	John577	
Change ? To: 1-Enable (on), 2-Disable (off)	xoayhamox	
Change ? To: 0-Disable (off), 1-Enable (on-default)	AngelDeath	
Change ? To: Subtract 2 from your current setting (if A, then A-2=8, if 2, then 2-2=0, etc.) to disable (turn off) ANC/ fake engine noise played through speakers ( <b>Ecoboost &amp; GT350 only</b> )		
Press and hold Left 'OK' button on Steering Wheel, Start Car, Continue holding Left 'OK' button until Engineer Data shows on Instrument Cluster	NasaStang	
Shows vacuum/boost gauge on center cluster	00Racer	

**Current as of: 13 Aug 2018**

Action	Contributor/ Verified By:	
Shows vacuum/boost, oil pressure and transmission temp on center cluster (Lose Volt gauge ?)	leszek	
IPC change is the challenge: If the ? is an 8-change to C, If the ? is something else-then add 4	leszek	Note: You must be in 'D' (automatic) or Parking Brake released (manual) for the Fog Lights to come on...this does not affect the "Fin" lights
Allow All DRL Options - no errors (change this first, then select your DRL option below)	DanMc85	
Change ?? To: 01 = Disabled / Parking Lights Only (see option 1 to the left) 02 = Low Beams 04 = Front Fog Lamps 08 = Front Turn Lamps 10 = Dedicated DRL Lights (LED Light Bars/Strips) - Enables BCM DRL Outputs - C2280F Pins 36 (Right) and 40 (Left) 20 = High Beams 40 = Low Beams and Dedicated DRL Lights	DanMc85	
Change all three lines of BCM code to get Fog & Parking Lights to come on as DRLs	Gman	
Enable	AngelDeath	
Enable	AngelDeath	
Change ? To: 0 - Disable (off), 1 - Enable (on-default)	Falk03	
Change ? To: 0 - Enable (on), 1 - Disable (off)	AngelDeath	
Enable/Disable using the FORSCAN Drop-down menus	dave-	
Change both lines to enable Lock options in IPC	DanMc85 (via Nuked)	NOTE: These are the same settings for the Auto-Relock option posted above...please let me know which code/listing you prefer (and works)
Change ? to: 0-Disabled (off), 4-Enabled (on)	solodogg	
Enable	Nemesis911	
Disable		
Enable		

**Current as of: 13 Aug 2018**

Action	Contributor/ Verified By:	
Change ? to: 5-Disable (off-default), 7-Enable (Non-US Region)		
Disable		
Enable		
Enable		
Enable		
Enable		
Enable		
Change ? To: B to show car icon on rear camera view (this works on Sync 2 and Sync 3)	xoayhamox jbailer	
Change ?? To: 08-Disable (off), 1A-Enable (on)	solodogg	
Change ? To: 0-Disable (off-default), 1-Enable (on)	Redraven57 1	
Change ? To: 0-disable all (turn off), 2-disable Driver, 4-disable Passenger, 6-enable	jsn1	
If car is running and fob is removed, shifter can't be moved from Park		
Change ???? To: value as calculated in the link to the right	Spart	<a href="https://docs.google.com/spreadsheets/d/1mWnuQZIDTUGjKjmJje1QJIR8Z2c7Kf8KBZxKnw_8EqU/edit?usp=sharing">https://docs.google.com/spreadsheets/d/1mWnuQZIDTUGjKjmJje1QJIR8Z2c7Kf8KBZxKnw_8EqU/edit?usp=sharing</a>
Change ? To: 0-Disable (default), 8-Enable (switch functions)	Gman	
	Spart	
Change ? To: 0-Round (default), 1-Square	EastTNMustang	
Change ? To: A-Off, 2-20 minutes, 3-30 minutes, 4-40 minutes, 5-50 minutes, 6-60 minutes		
Change ? To: A to enable (turn on) Radio Station Label if RDS instead of just radio frequency	jbailer	
Change to get HD Radio Available on Radio Settings Screen	djcwardog	

**Current as of: 13 Aug 2018**

Action	Contributor/ Verified By:	
Change ? To: x0x2	dotJake	
Change ? To: 0-Disable (off), 1-Seat Cooling, 2-Seat Heating/Cooling, 3-Seat Heating, 4-Heated Steering Wheel, 6-All		
Change to enable HD radio - (non-HD radios have a value of 8)	djewardog	
Change ? To: 1 to enable (turn on) Radio Station Label if RDS instead of just radio frequency	xoayhamox	
Change ? To: Subtract 2 from your current setting (if A, then A-2=8, if 2, then 2-2=0, etc.) to remove Sirius as an Audio source	Gman	
Change both lines to enable Lincoln/brown screen theme	EastTNMustang	
Change ? To: 0=Ford Classic, 1=Ford Timeless, 2=Lincoln Timeless, 3=Lincoln Next, 4=Ford New Blue GT	AngelDeath	
Change ? To: 2-Ford, 3-Lincoln Black Label, 4-Lincoln Presidential, 5-Raptor, 6-Mustang GT, 7-GT350 Gray, 8-Vignale, 9-GT350R Red, A-Ford, B-ST, C-RS, D-GT, E-Continental, F-Ford		
Change ? To: 0-disable (turn off)	jsn1	
Change ? To: C-disabled (off), D-enabled (on)	solodogg	
Change ? To: 0-Disable (off), 1-Enable (on-default)		
Change ? To: 1-on (default), 0-off (no hyperflash)	D24112	
Change ? To: 0-3=1 flash, 4-5=2 flashes, 6-7=3 flashes, 8-9=4 flashes, A-B=5 flashes, C-D=6 flashes, E-F=7 flashes		
Change ? To: 0-Internal IPC speaker, 4-ACM/Vehicle Speakers (default)	solodogg	
VIN #: (first 5 characters in ASCII converted to Hex)	fionic	





































































































































































